

# HECATE




## G2000 PRO

### 2.0 Gaming Speakers

#### — Manual —

## EN


### 1. What's in the box?



#### Note:

- Images are for illustrative purpose only and may differ from the actual product.
- For the need of technical improvement and system upgrade, information and specifications contained herein may be slightly different from actual product. If any difference is found, the actual product prevails.

### 2. Power connection



#### Caution

To prevent damage to the product or connected devices, do not use adapters or other equipment with an output power exceeding 100 W (including 100 W) to power this product.

### 3. Power on/off



Power on: Press and hold the "ⓘ" button for 1s.  
Power off: Press and hold the "ⓘ" button for 2s.

### 4. Connection method


#### • USB audio streaming input



Press the "ⓘ" button to switch to USB audio streaming input with three beep tones, and the cyan indicator will remain on. Connect to an audio device with the USB audio cable.


Note: The product defaults to USB audio streaming input when first used.

#### • AUX input



Press the "ⓘ" button to switch to AUX input with two beep tones, and the red indicator will remain on.

#### • Bluetooth connection



1. Press the "ⓘ" button to switch to Bluetooth input with beep tone, and the blue indicator will blink. Select "HECATE G2000 PRO" from your device list to connect, and the white indicator will remain on when connected.


2. Double press the "ⓘ" to disconnect the Bluetooth and clear paired devices

### 5. Headphone Output




Connect your headphones to the speaker via the "Headphone Output" port, and the sound can be heard via your headphones.

### 6. Volume control




Volume Up: Press the "+" button. Volume Down: Press the "-" button.

### 7. Prompt tone on/off



Press and hold the "ⓘ" button and "+" button for 2s to turn on/off prompt tone.

### 8. Sound effects



Press the "G" button to switch sound effects.


Music mode: purple indicator blinks.

Gaming mode: red indicator blinks.

Movie mode: rows of blue indicator blinks intermittently.

Note: The product defaults to music mode when first used.


### 9. Light effects



Press and hold the "G" button for 2s to turn on/off light effects.

Double-press the "G" button to switch light effects.

### 10. Reset



In ON state, press and hold the "G" button and "ⓘ" button for 5s to restore to factory settings.

### 11. Specifications

Total output power: L/R: 16 W+16 W

Frequency response: 75 Hz-20 kHz

Input: 15 V  $\overline{\text{---}}$  4 A

### 12. Sound effect adjustment software

1. Please log in HECATE home page website: [www.hecategaming.com](http://www.hecategaming.com) to download software of G2000 PRO, find the "setup.exe" file, and install the HECATE software (Windows 10 or later systems supported).

2. Please follow the instructions to complete the installation.